



FCT

Ø11 Flexible Rogowski coil

- High linearity from 1A to 100kA
- Wide dynamic range
- Very useful with large size or awkward shaped conductors or in places with limited access
- No danger from open-circuited secondary
- Not damaged by large overloads
- Non-intrusive, no power drawn from the main
- Measurement uniformity at any position of the conductor inside the coil
- Excellent degree of rejection to the external current conductor

Feature

FCT is a flexible current transducer based on Rogowski principle, particularly suitable for measurement in combination with portable devices. FCT coils are available in different sizes and can be supplied according to customer's design, therefore they can be used in all those applications, in which traditional transducers are not fitting due to its size and/or weight.

Due to its specific features, flexible Rogowski coil is an extremely confortable solution for current measurement and can be used in a number of cases where traditional current transducer is not the adequate solution.

FCT coil is provided with a shield against the influence of external magnetic fields, therefore it grants a stable measurement from low currents to hundreds of kA. The Rogowski coils must be connected to an electronic integrator

for 90° phase shift compensation and frequency equalization. Our DIN-RAIL and panel meters can interface Rogowski

coils directly without the need of the external integrators. This is an advantage because there is no external boxes or any power supply with consequent ease of use. The particular features of the Rogowski coils combined with the extremely flexible input programming of our portable meters, allow to carry out measurement by all applications.

Advantage

- Calibrated to 0.5%
- 11mm section make more stable
- Total shielded
- Lower zero drift down to 1mV

Related Products

S1 D1 S9 SW A01 A05 ME631 ME432

Applications

- Measuring devices, lab instrumentation
- Power monitoring & control systems
- DC ripple measurement
- Harmonics and transients monitoring
- Power meter,Power analyzer sensor

What is a Rogowski coil?

Rogowski coils have been used for the detection and measurement of electric currents for decades. They are based on a simple principle: an "air-cored" coil is placed around the conductor in a toroidal fashion and the magnetic field produced by the current induces a voltage in the coil. The voltage output is proportional to the rate of change of current. This voltage is integrated, thus producing an output proportional to the current. By using precision winding techniques, especially developed for the purpose, the coils are manufactured so that their output is not influenced by the position of the conductor within the toroid, and to reject interference from external magnetic fields caused, for example, from nearby conductors.Basically, a Rogowski coil current measuring system consists of a combination of a coil and conditioning electronics.Rogowski coil current transducers are used for the AC measurement.

They can be used in similar circumstances to current transformers but for many applications they have considerable advantages:

- Wide dynamic range.
- High linearity.

• Very useful with large size or awkward shaped conductors or in places with limited access. Thanks to the structure without hard core, the coil can be easily manufactured according to the application or to the available space.

• Unlike traditional current transducers, there is no danger from open-circuited secondaries.

They cannot be damaged by large overloads.

• They are non-intrusive. They draw no power from the main circuit carrying the current to be measured.

• They are also light weighted and in some applications are light enough to be suspended on the conductor being measured.

The transducer does not measure direct currents but, unlike a current transformer, it can carry out accurate measurements of AC component even if there is a large superimposed DC component, since there is no iron core causing saturation. This feature is particularly useful for measuring ripple currents for example in battery charging systems.



Specification

MODEL	FCT-420)	FCT-510	FCT-620	FCT-800	
Coil length	420mm		510mm	620mm	800mm	
Window size	120mm		150mm	185mm	240mm	
Weight	105g		120g	135g	165g	
Reference Rated current	1000A		3000A	6000A	10kA	
Coil Resistance		from 100 to 300 Ω				
Coil Section	11mm					
Lead length	2meter					
	Uncalibrated	120mV/kA@50Hz				
Output (di/dt)		50mV/kA@50Hz				
	Calibrated		85mV/kA@50Hz			
		100mV/kA@50Hz				
Dood Acourcov		Calibrated <0.5% (central position, 25°C)				
Read Accuracy		Uncalibrated < 5% tolerance (central position, 25° C)				
Temperature	Uncalibrated 200ppm/C					
Temperature	Calibrated 300ppm/C					
Position Error	\pm 1% maximum					
Output on 0A (zero drift)	≤0.05mV					
Phase error	≪0.5°					
Linearity	±0.2% of reading					
Bandwidth	1Hz to 1MHz(-3dB)					
Operating temperature	-30℃ to 80℃					
Storage temperature		-40℃ to 90℃				
	Ot	her require	ments, please co	ontact us to OEM.		





Position sensitivity

Conductor Position	Typical Error(%)
Adjacent to the center of coil	0.2%
Adjacent to the inside of coil	<1%

Materials

Coil & cable	Silicone	
	flame retardant UL 94 V-0 rated PA6 UL 94 V-0 rated Grey	
Couplings	PA6 UL 94 V-O rated	
Color(coil)	Grey	
Shielded	100% coil, 100% output cable	

Safety

	CE marked	
	Complies with	
Certifications	LVD EN 61010-1:2010	
	EMC EN 61326-1:2013	
	IP68	
	Coil: 3000V	
Voltage insulation	Signal cable:1000V	
Safety	1000V CATIII ,600V CATIV	







Dimensions tolerance: A,B,C,F: \pm 5mm, D: \pm 0.2mm,E: \pm 10mm

Dimensions(mm)	FCT-420	FCT-510	FCT-620	FCT-800
A.Windows size A	125	155	190	245
B.Windows size B	120	150	185	240
C.Coil O.D.	147	172	202	267
D.Coil section	11			
E.Lead Cable Total Length	2000			
F:Coil length	420	510	620	800
ROGOWSKI COIL FCT		5		www.rogowski.cn



Safety and warning notes

In order to guarantee safe operation of the transducer and to be able to make proper use of all features and functions, please read these instructions thoroughly!Safe operation can only be guaranteed if the transducer is used for the purpose it has been designed for and within the limits of the technical specifications.Ensure you get up-to-date technical information that can be found in the latest associated datasheet under <u>www.rogowski.cn</u>

Caution!Risk of danger

Ignoring the warnings can lead to serious injury and/or cause damage!

The electric measuring transducer may only be installed and put into operation by qualified personnel that have received an appropriate training, The corresponding national regulations shall be observed during installation and operation of the transducer and any electrical conductor. The transducer shall be used in electric/electronic equipment the respect to applicable standards and safety requirements and in accordance with all the related systems and components manufacturers' operating instructions.

Caution!Risk of electrical shock

When operating the transducer, certain parts of the module may carry hazardous live voltage (e.g. primary conductor). The user shall ensure to take all measures necessary to protect against electrical shock. The transducer is a build-in device containing conducting parts that shall not be accessible after installation. A protective enclosure or additional insulation barrier may be necessary. Installation and maintenance shall be done with the main power supply disconnected except if there are no hazardous live parts in or in close proximity to the system and if the applicable national regulations are fully observed.

Safe and trouble-free operation of this transducer can only be guaranteed if transport, storage and installation are carried out correctly and operation and maintenance are carried out with care.

WARING!

Do not stress the coil by applying any kind of mechanical force(ie.twisting,puncturing,excessive pressure,tight bending,etc.) which will dramatically degrade the device's accuracy.



Order code

Coil:

Coil Model	Coil diameter (mm)	Output ratio and tolerance	Signal cable length
	Code:200(Typical rated 500A)	Code:110	
	Code:350(Typical rated 1500A)	110mV/kA@50Hz±5%	
Code:Y-FCT	Code:510(Typical rated 3kA)	Code:100	
	Code:800(Typical rated 10kA)	100mV/kA@50Hz±0.5%	
	Y-FCT code is length.	Code:85	
	Code:100(Typical rated 1kA)	85mV/kA@50Hz±0.5%	
Code:NRC	Code:150(Typical rated 3kA)	Code:50	
	Code:200(Typical rated 6kA)	50mV/kA@50Hz±0.5%	
Code:MRC	Code:16(Typical rated 100A) Code:24(Typical rated 300A) Code:36(Typical rated 600A)	Code:60 60mV/kA@50Hz±5% Code:50 50mV/kA@50Hz±0.5%	Code:-2m Code:-5m Code:-10m
Code:SRC	Code:50 Code:100 Code:150	Code:360 360mV/kA@50Hz±5% Code:333 333mV/kA@50Hz±0.5% Code:100 100mV/kA@50Hz±0.5% Code:85 85mV/kA@50Hz±0.5% Code:50 50mV/kA@50Hz±0.5%	Code:-20m
	Other requirement of	could be OEM	

Final Code=Coil model+Coil length(MRC NRC is diameter)+Output ratio tolerance+Signal cable length

For example:

Y-FCT-350-100-2m is Y shape connector,coil length 350mm,output 100mV/kA@50Hz 0.5% tolerance,signal cable length is 2meter.

MEATROL® Measure life, Control future

Integrator:

Integrator	Output form	Output value	Rated current	Power supply
Code: D1 (DIN-RAIL integrator)	Code: .1(AC voltage output) Code: .2(DC voltage output) Code: .3(4-20mA output)	Code: -333(333mV) Code: -1(1V) Code: -5(5V)	-	Code: -12(12V DC) Code: -24(24V DC)
Code:S9 (mini integrator)	Code: .1(AC voltage output) Code: .2(DC voltage output)	Code: -333(333mV) Code: -1(1V) Code: -3(3V)		Code: -12(6-12V DC) Code: -24(24V DC)
Code: S1 (high accuracy integrator)	Code: .1(AC voltage output) Code: .2(DC voltage output)	Code: -333(333mV) Code: -5(5V) Code: -10(10V)	Code: -600A	Code: -12(4-12V DC) Code: -24(24V DC)
	Code: .3(4-20mA output)	N/A	Code: -1kA Code: -3kA	
Code: ATP-01 (1A output three phase integrator)	N/A (0-1A)	N/A	Code: -6kA	Code: -12(12V DC) Code: -24(24V DC)
Code: A01 (1A output integrator)	N/A (0-1A)	N/A		N/A(85-265V AC DC)
Code: A05 (5A output integrator)	N/A (0-5A)	N/A		N/A(85-265V AC DC)
Code: HF (high frequency integrator)	N/A (0-10VAC peak)	N/A	Code: -1kA(1kA/1V) Code: -10kA(10kA/1V)	N/A(4-12V DC)

Other requirement could be OEM

Final Code=Integrator+Output form+Output value+Rated current+Power supply

For example:

D1.1-1-500A-12 is D1 integrator,AC voltage output,500A rated,output 1V,power supply 12V DC

A01-1kA is A01 integrator, rated 1kA, output 1A, power supply 85-265V AC DC