


How to use





FSCT

Waterproof Split Core Current Transformer

- High linearity from 1A to 100kA
- Wide dynamic range
- No danger from open-circuited secondary
- Not damaged by large overloads
- Non-intrusive, no power drawn from the main
- Measurement uniformity at any position of the conductor inside the coil
- Excellent degree of rejection to the external current conductor

Feature

FSCT Waterproof current transformer is built with silicone steel core and is potted for outdoor use. In addition, it is designed for easy installation on ground potential conductors.

ROGOWSKI COIL FSCT 1 www.meatrol.cn



Advantage

- Calibrated to 0.5%
- Lower zero drift down to 0.05mV
- Competitive cost
- Waterproof

Related Products

S1 D1 S9 SW A01 A05 ME631 ME432

Applications

- Measuring devices, lab instrumentation
- Power monitoring & control systems
- Distributed measurement systems
- Measurement of current power supply equipment below 10KV
- Microcomputer protection
- Power meter, Power analyzer sensor

What is a Rogowski coil?

Rogowski coils have been used for the detection and measurement of electric currents for decades. They are based on a simple principle: an "air-cored" coil is placed around the conductor in a toroidal fashion and the magnetic field produced by the current induces a voltage in the coil. The voltage output is proportional to the rate of change of current. This voltage is integrated, thus producing an output proportional to the current. By using precision winding techniques, especially developed for the purpose, the coils are manufactured so that their output is not influenced by the position of the conductor within the toroid, and to reject interference from external magnetic fields caused, for example, from nearby conductors.Basically, a Rogowski coil current measuring system consists of a combination of a coil and conditioning electronics.Rogowski coil current transducers are used for the AC measurement.

They can be used in similar circumstances to current transformers but for many applications they have considerable advantages:

- · Wide dynamic range.
- · High linearity.
- Very useful with large size or awkward shaped conductors or in places with limited access. Thanks to the structure without hard core, the coil can be easily manufactured according to the application or to the available space.
- Unlike traditional current transducers, there is no danger from open-circuited secondaries.
- They cannot be damaged by large overloads.
- They are non-intrusive. They draw no power from the main circuit carrying the current to be measured.
- They are also light weighted and in some applications are light enough to be suspended on the conductor being measured.

The transducer does not measure direct currents but, unlike a current transformer, it can carry out accurate measurements of AC component even if there is a large superimposed DC component, since there is no iron core causing saturation. This feature is particularly useful for measuring ripple currents for example in battery charging systems.

ROGOWSKI COIL FSCT 2 www.meatrol.cn




Specification

MODEL	FSCT			
Window size	60mm			
Rated primary current	100-5000 Arms			
Max current	5000 Arms			
Rated Secondary Current	5A or 1A			
Burden	1.5VA - 15VA			
Rated output	5A/1A			
Equipment maximum voltage	0.66/0.72KV			
Read Accuracy	Calibrated <0.5% (central position, 25℃) Uncalibrated < 1% tolerance (central position, 25℃)			
Temperature —	Uncalibrated 200ppm/C			
romporataro	Calibrated 300ppm/C			
Position Error	\pm 1% maximum			
Output on 0A (zero drift)	≤0.05mV			
Phase error	≤0.5°			
Linearity	±0.2% of reading			
Safety Factor Rating	< 10			
Wire lead	2*2.5mm2 sheathed wire			
Insulation strength	3KVac/min			
Insulation impedance	DC500V/100M Ω			
Rated frequency	50-400HZ			
Operating temperature	—25℃~70℃			
Storage temperature	—30℃~80°C			
Operation Condition	Outdoor			
Other requirements, please contact us to OEM.				

ROGOWSKI COIL FSCT 3 www.meatrol.cn



Dimensions



Materials

Housing	PA66
---------	------

Safety

	CE marked	
Certifications	Complies with EMC EN 61326-1 2006	
	IP68	
Voltage insulation	Housing: 10kV	
	Signal cable:1000V	
Safety	1000V CATIII ,600V CATIV	
Signal cable	Ф4mm, 2*0.2mm² 200°С	

ROGOWSKI COIL FSCT 4 www.meatrol.cn



Safety and warning notes

In order to guarantee safe operation of the transducer and to be able to make proper use of all features and functions, please read these instructions thoroughly! Safe operation can only be guaranteed if the transducer is used for the purpose it has been designed for and within the limits of the technical specifications. Ensure you get up-to-date technical information that can be found in the latest associated datasheet under www.meatrol.cn

Caution!Risk of danger

Ignoring the warnings can lead to serious injury and/or cause damage!

The electric measuring transducer may only be installed and put into operation by qualified personnel that have received an appropriate training, The corresponding national regulations shall be observed during installation and operation of the transducer and any electrical conductor. The transducer shall be used in electric/electronic equipment the respect to applicable standards and safety requirements and in accordance with all the related systems and components manufacturers' operating instructions.

Caution!Risk of electrical shock

When operating the transducer, certain parts of the module may carry hazardous live voltage (e.g. primary conductor). The user shall ensure to take all measures necessary to protect against electrical shock. The transducer is a build-in device containing conducting parts that shall not be accessible after installation. A protective enclosure or additional insulation barrier may be necessary. Installation and maintenance shall be done with the main power supply disconnected except if there are no hazardous live parts in or in close proximity to the system and if the applicable national regulations are fully observed.

Safe and trouble-free operation of this transducer can only be guaranteed if transport, storage and installation are carried out correctly and operation and maintenance are carried out with care.

WARING!

Do not stress the coil by applying any kind of mechanical force(ie.twisting,puncturing,excessive pressure,tight bending,etc.) which will dramatically degrade the device's accuracy.

ROGOWSKI COIL FSCT 5 <u>www.meatrol.cn</u>



Order code

Coil:

Coil Model	Coil length (mm)	Output ratio and tolerance	Signal cable length
		Code:105	
	Code:200(Typical rated 500A)	105mV/kA@50Hz±5%	
	Code:350(Typical rated 1500A)	Code:105 105mV/kA@50Hz±5% 105mV/kA@50Hz±5% 100mV/kA@50Hz±5% 100mV/kA@50Hz±0.5% 100mV/kA@50Hz±0.5% 100mV/kA@50Hz±5% 100mV/kA@50Hz±5	
		100mV/kA@50Hz±0.5%	
		Code:95	Code:-2m
Code:Y-FCY	Code:510/Typical rated 2kA)	Code:105 ated 500A) ated 1500A) Code:100 100mV/kA@50Hz±0.5% Code:95 95mV/kA@50Hz±5% Code:85 85mV/kA@50Hz±0.5% Code:30 30mV/kA@50Hz±5% Code:30 30mV/kA@50Hz±5% Code:120 ated 3kA) ated 3kA) ated 6kA) ated 6kA) ated 10kA) Code:100 ated 10kA) Code:50 50mV/kA@50Hz±5% Code:100 ated 300A) ated 300A) ated 300A) ated 300A) ated 600A) Code:60 60mV/kA@50Hz±5% Code:105 105mV/kA@50Hz±5%	Code:-5m
(without integrator)	Code.510(Typical fated 5kA)	Code:85	Code:-10m
		85mV/kA@50Hz±0.5%	Code:-20m
		Code:50	
	Code:800(Typical rated 10kA)	50mV/kA@50Hz±5%	
		Code:30	
		30mV/kA@50Hz±0.5%	
	Code:420(Typical rated 2kA)	Code:120	Code:-2m
Code:FCT	Code:FCTCode:510(Typical rated 3kA)120mV/kA@50Hz±5%out integrator)Code:620(Typical rated 6kA)Code:100	Code:-5m	
(without integrator)		Code:100	Code:-10m
		100mV/kA@50Hz±0.5%	Code:-20m
	0 - do 40(Tomic of motor d 400A)	Code:50	Code:-2m
MRC	, , ,	Code:105 105mV/kA@50Hz±5% Code:100 100mV/kA@50Hz±0.5% Code:95 95mV/kA@50Hz±5% Code:85 85mV/kA@50Hz±5% Code:50 50mV/kA@50Hz±5% Code:120 120mV/kA@50Hz±5% Code:120 120mV/kA@50Hz±5% Code:100 100mV/kA@50Hz±0.5% Code:50 50mV/kA@50Hz±5% Code:50 50mV/kA@50Hz±5% Code:50 50mV/kA@50Hz±5% Code:60 60mV/kA@50Hz±5% Code:105 105mV/kA@50Hz±5% Code:105 105mV/kA@50Hz±5% Code:100 100mV/kA@50Hz±5%	Code:-5m
WIKC	,		Code:-10m
	Code.30(Typical faled 000A)		Code:-20m
		Code:105	Code:-2m
NDC	, , , ,	Code:100 100mV/kA@50Hz±0.5% Code:50 50mV/kA@50Hz±0.5% Code:60 60mV/kA@50Hz±5% Code:105 105mV/kA@50Hz±5%	Code:-5m
NRC	, , , ,	Code:100	Code:-10m
	Oute.200(Typical fated 6KA)	100mV/kA@50Hz±0.5%	Code:-20m
	Other requirement c	ould be OEM	•

Final Code=Coil model+Coil length(MRC NRC is diameter)+Output ratio tolerance+Signal cable length For example:

Y-FCT-350-100-2m is Y shape connector,coil length 350mm,output 100mV/kA@50Hz 0.5% tolerance,signal cable length is 2meter.

ROGOWSKI COIL FSCT 6 www.meatrol.cn



Integrator:

Output form	Output value	Rated current	Power supply
Code: .1(AC voltage output) Code: .2(DC voltage output)	Code: -333(333mV) Code: -1(1V) Code: -3(3V) Code: -5(5V)	Code: -500A Code: -1kA Code: -3kA	Code: -12(12V DC) Code: -24(24V DC)
Code: .3(4-20mA output)	N/A	oodo: Tokka	
Code: .1(AC voltage output) Code: .2(DC voltage output)	Code: -333(333mV) Code: -1(1V) Code: -3(3V)	Code: -500A Code: -1kA Code: -3kA Code: -10kA	Code: -12(6-12V DC) Code: -24(24V DC)
Code: .1(AC voltage output) Code: .2(DC voltage output) Code: .3(4-20mA output)	Code: -333(333mV) Code: -1(1V) Code: -3(3V) Code: -10(10V)	Code: -500A Code: -1kA Code: -3kA Code: -10kA	Code: -12(4-12V DC) Code: -24(24V DC)
Code: .1(AC voltage output) Code: .2(DC voltage output)	Code: -333(333mV) Code: -1(1V) Code: -3(3V) Code: -10(10V)	Code: -500A Code: -1kA Code: -3kA Code: -10kA	Code: -12(4-12V DC) Code: -24(24V DC)
N/A (0-1A)	N/A	Code: -500A Code: -1kA Code: -3kA Code: -10kA	N/A(85-265V AC DC)
N/A (0-5A)	N/A	Code: -500A Code: -1kA Code: -3kA Code: -10kA	N/A(85-265V AC DC)
N/A (0-10VDC)	N/A	Code: -10kA Code: -50kA Code: -100kA Code: -500kA	Code: -12(4-12V DC) Code: -24(24V DC)
N/A (0-10VAC peak)	N/A	Code: -1kA(1kA/1V) Code: -10kA(10kA/1V)	N/A(4-12V DC)
N/A(0-5VAC peak)	Code: -333(333mV) Code: -1(1V)	Code: -100A Code: -500A Code: -1kA Code: -3kA	Code: -3.3(±3.3V DC) Code: -5(±5V DC)
	Code: .1(AC voltage output) Code: .2(DC voltage output) Code: .3(4-20mA output) Code: .1(AC voltage output) Code: .2(DC voltage output) Code: .2(DC voltage output) Code: .3(4-20mA output) Code: .1(AC voltage output) Code: .2(DC voltage output) N/A(0-1A) N/A(0-1A) N/A(0-1A)	Code: .1(AC voltage output) Code: .2(DC voltage output) Code: .3(3333mV) Code: .3(3V) Code: .3(3V) Code: .5(5V) Code: .1(AC voltage output) Code: .2(DC voltage output) Code: .2(DC voltage output) Code: .2(DC voltage output) Code: .3(3V) Code: .1(1V) Code: .3(3V) Code: .1(1V) Code: .3(3V) Code: .1(1V) Code: .2(DC voltage output) Code: .2(DC voltage output) Code: .1(1V) Code: .3(3V) Code: .1(1V) Code: .3(3V) Code: -10(10V) N/A(0-1A) N/A(0-1A) N/A N/A(0-10VDC) N/A N/A Code: -333(333mV) Code: -333(333mV)	Code: .1(AC voltage output) Code: .2(DC voltage output) Code: .3(34-20mA output) Code: .3(34-20mA output) Code: .4(AC voltage output) Code: .3(34-20mA output) Code: .4(AC voltage output) Code: .4(AC

Final Code=Integrator+Output form+Output value+Rated current+Power supply

For example:

D1.1-1-500A-12 is D1 integrator,AC voltage output,500A rated,output 1V,power supply 12V DC A01-1kA is A01 integrator,rated 1kA,output 1A,power supply 85-265V AC DC